


4-POST Open Frame Rack Assembly Instruction




Packaging List


- 1. Vertical rail - 4pcs
- 2. Horizontal beam - 4pcs
- 3. Plinth - 2pcs
- 4. 2" heavy-duty castor (2 pcs with brake) - 4pcs
- 5. Top connection part - 2pcs

In support of our policy of continuous product improvement we reserve the right to change materials and specifications without notice. Drawings, where used, are not to scale. All dimensions are in millimetres and sizes given are approximate. Where possible, technical MSDS data sheets are made available on the website. All products should be installed and used in accordance with manufacturer's instructions provided. Warning: products may be the subject of registered designs and patents. Refer to website for terms and conditions on warranty.


Dimensions




Front View



Side View



Top View



In support of our policy of continuous product improvement we reserve the right to change materials and specifications without notice. Drawings, where used, are not to scale. All dimensions are in millimetres and sizes given are approximate. Where possible, technical MSDS data sheets are made available on the website. All products should be installed and used in accordance with manufacturer's instructions provided. Warning: products may be the subject of registered designs and patents. Refer to website for terms and conditions on warranty.

Item List of Accessories Packaging

Assembly Hardwares Kits:






- M6*12 screw - 72pcs
- M6 Flange nut - 72pcs
- 2" heavy-duty castor -2pcs
- 2" heavy-duty castor with brake -2pcs

End User Hardwares Kits:

U Capacity $\leq 27U$, 20 sets cagenuts ; $27U < U$ Capacity $\leq 37U$, 30sets cagenuts ; U Capacity $> 37U$, 40 sets cagenuts.
(cagenut : M6*12 screw & M6 cage nut)


Tips: Check the quantities of the items before assembly

Diagram of accessories


NO.	FIGURE	DESCRIPTION
1		M6 flange nut
2		M6*12 Screw
3		2" heavy-duty castor
4		2" heavy-duty castor with brake
5		M6 cage nut

In support of our policy of continuous product improvement we reserve the right to change materials and specifications without notice. Drawings, where used, are not to scale. All dimensions are in millimetres and sizes given are approximate. Where possible, technical MSDS data sheets are made available on the website. All products should be installed and used in accordance with manufacturer's instructions provided. Warning: products may be the subject of registered designs and patents. Refer to website for terms and conditions on warranty.

Installation




Step 1: Assembly vertical rails and horizontal beams to form the frame with 32 sets M6*12 screws and M6 flange nuts.




Step 2: Assembly the castors on the Plinths by 16 sets M6*12 screws and M6 flange nuts.

In support of our policy of continuous product improvement we reserve the right to change materials and specifications without notice. Drawings are for reference only. All dimensions are in millimetres and sizes given are approximate. Where possible, technical MSDS data sheets are made available on the website. All products should be installed and used in accordance with manufacturer's instructions provided. Warning: products may be the subject of registered designs and patents. Refer to website for terms and conditions on warranty.



Step 3: Assembly the frame and plinth by 16 sets M6*12 screws and M6 flange nuts.



Step 4: Assembly the top connection part on the frames by 8 sets M6*12 screws and M6 flange nuts.

Note: After assembly, please adjust the diagonal size of the cabinet to ensure homogeneous space for all doors and all doors work well.

In support of our policy of continuous product improvement we reserve the right to change materials and specifications without notice. Drawings, where used, are not to scale. All dimensions are in millimetres and sizes given are approximate. Where possible, technical MSDS data sheets are made available on the website. All products should be installed and used in accordance with manufacturer's instructions provided. Warning: products may be the subject of registered designs and patents. Refer to website for terms and conditions on warranty.